

Overview

The Lift Kit enables adjustable tenting of your **Freestyle Edge** split keyboard for maximum comfort and stamina. Attach the Lift Kit's two "v-lifters" and choose from 3 tenting angles (5°, 10°, or 15°) to suit your gaming preferences. You'll never want to use a flat keyboard again.

Why Tent?

Tenting is the elevation of the center of a split keyboard to raise the thumb-side of your hands. Traditional keyboards force you to type with your palms face-down towards the desk. This posture increases pressure on the forearm muscles and surrounding tissues which causes fatigue, slows reflexes, and can even lead to serious injury. The Lift Kit positions your hands and arms in a relaxed posture so you can play longer and take fewer breaks.

Installation

1. Unplug the keyboard and flip it over (with Palm Supports).
2. Match the left v-lifter to the left key module and vice versa. Insert the two "end-tabs" on the v-lifter into the square holes on the keyboard at a 90° angle. Once both end-tabs are in place, lower the other end of the v-lifter until the two "squeeze-tabs" lock securely into the Palm Support.



*Palm Supports required for Lift Kit.


Removal

- Do not attempt to remove a Palm Support while a v-lifter is attached.
1. Unplug the keyboard and flip it over.
 2. Gently press the squeeze-tabs together. Then lift straight up on the squeeze-tab end of the v-lifter until the two end-tabs can be disengaged from the keyboard.

Adjusting Tenting Angle

You can quickly move between all 3 tenting angles without detaching the Lift Kit from the keyboard.

Each v-lifter has two hinged legs which, when unsnapped, can lie flat to provide 5° tenting. For higher tenting, snap the legs together to form a rigid "v". Then swivel the legs in for 10° tenting, or swivel them out for 15° tenting.



PERFORMANCE



COMFORT



CONTROL



Designed in the USA. Manufactured in Taiwan.
©2017 Kinesis Corporation. All Rights Reserved.

KINESISGAMING.COM

ELEVATE YOUR GAME

LIFT KIT

Tenting accessory for the Freestyle Edge



KinesisGaming

Tips & Troubleshooting

- For best results, start at 5° so your body can adapt to tenting. Then experiment with 10° and 15° to find the optimal setting.
- If the keyboard feels unstable, the v-lifters may be installed on the wrong side, or the legs may not be fully snapped into a rigid "v".

Support

Kinesis Gaming Tech Support is available Monday–Friday during normal business hours (Pacific Time).

(425) 402-8100

Tech@Kinesis.com

KinesisGaming.Com/Support

@KinesisGaming #ElevateYourGame